

BioStim, LLC PO Box 1737 Boerne, TX 78006 Phone (800) 338-8812 Fax (830) 336-4827 www.biostim.com



# KB4-F DRAIN LINE FORMULA

For use in floor drains, soda fountain drains, beer tap drains, ice cream dipper well drains, ice machine drains, bar sink drains, soda holster drains and other types of drains. Use *Drain Line BioFoam* for more even distribution of microbes.

## **Application Instructions:**

Mix with two gallons of water in a 2 gallon sprayer. Spray 2 to 3 ounces per soda fountain type drain. Spray 8 ounces per floor drain. Calibrate pump at full pressure to determine how many seconds to spray; maintain full pressure during use. Use all product at time of service. Do not store after mixing. Repeat monthly.

#### Storage:

Store at ambient temperature; do not allow to freeze.

## **Product Information:**

Environmentally friendly Safe for plumbing lines and septic systems Contains no corrosive or caustic chemicals No free enzymes or FOG emulsifiers

#### **Precautions:**

Do not ingest Keep out of reach of children Avoid contact with open wounds People with autoimmune deficiencies should avoid contact Non-flammable Does not cause pass-through Multiple strains of naturally occurring bacteria

Do not inhale Wear latex gloves for hygiene Avoid contact with eyes, nose, or mouth Wash hands with soap and water after handling

## First Aid:

In case of contact with <u>eyes</u>: flush with water for 15 minutes; seek medical attention if irritation persists. In case of contact with <u>skin</u>: wash with soap and water; remove contaminated clothing. In case of <u>inhalation</u>: remove victim to fresh air if trouble breathing; seek medical attention immediately. In case of <u>ingestion</u>: drink water to dilute; do NOT induce vomiting; seek medical attention immediately.

MSDS available at <u>www.biostim.com</u> under "Products" tab.

