



BioStim, LLC
PO Box 1737
Boerne, TX 78006
Phone (800) 338-8812
Fax (830) 336-4827
www.biostim.com



KBFF FAST FOOD / X-RAY FORMULA

For use in food service facility three-compartment sink drain lines, non-digital X-ray discharge drain lines, and kidney dialysis discharge drain lines and other appropriate drain lines. Delivered via an automatic injection pump to provide consistent treatment of drain lines. May be used in conjunction with *Injection Formula* and *BioPill*.

Application Instructions:

Remove pump from 5 gallon bucket if already attached. Clean bucket with water ONLY before adding new bacteria. Mix with 5 gallons of water in bucket. Reattach pump to bucket. Follow manufacture's instructions for pump. Use all of the mixture at time of service. Repeat monthly.

Storage:

Store at ambient temperature; do not allow to freeze.

Product Information:

Environmentally friendly
Safe for plumbing lines and septic systems
Contains no corrosive or caustic chemicals
No free enzymes or FOG emulsifiers

Non-flammable
Does not cause pass-through
Multiple strains of naturally occurring bacteria

Precautions:

Do not ingest
Keep out of reach of children
Avoid contact with open wounds
People with autoimmune deficiencies should avoid contact

Do not inhale
Wear latex gloves for hygiene
Avoid contact with eyes, nose, or mouth
Wash hands with soap and water after handling

First Aid:

In case of contact with eyes: flush with water for 15 minutes; seek medical attention if irritation persists.
In case of contact with skin: wash with soap and water; remove contaminated clothing.
In case of inhalation: remove victim to fresh air if trouble breathing; seek medical attention immediately.
In case of ingestion: drink water to dilute; do NOT induce vomiting; seek medical attention immediately.

MSDS available at www.biostim.com under "Products" tab.

Rev. Jan 2012

